# In-Swing Hinge Door Adjustable Hinge Repalcement

SERVICE INSTRUCTION

**These instructions apply to:**

Pella® Front Doors Clad Wood (CIS08) 2026 - Current
Pella® Reserve 2017 - Current
Pella® Lifestyle Series Dual-Pane 04/2019-Current
Pella® Lifestyle Series Triple-Pane 04/2019-Current
Architect Series® 2/2011-04/2024
Designer Series® 5/2013-03/2019
Pella® 450 Series 5/2015-03/2019

**Tools Required:**

Phillips screwdriver
T20 Torx wrench

**Supplies Needed:**

Replacement hinge and #10 T20 screw

**Note:** Adjustable hinges are **NOT** retrofitable on previous vintages or other brands of doors not listed above.

## 1 Removing The Hinge:

A. Grasp and pull the weatherstrip out of the frame kerf to access the entire frame hinge leaf.




B. Remove the screws from the frame hinge leaf.




C. Remove the top and bottom screw from the panel hinge leaf.




D. Use a T20 Torx wrench to loosen the center screw on the panel hinge leaf so that it clears the hinge rout.




© 2026 Pella Corporation