Transition Seal Replacement for In-Swing French Door

SERVICE INSTRUCTION

These instructions apply to:

Pella® Front Doors – Clad Wood (CIS08) 2026 - Current
Pella® Lifestyle Series Dual-Pane 04/2019 - Current
Pella® Lifestyle SeriesTriple-Pane 04/2019 - Current
Pella® Reserve 2017 - Current
Architect Series® 2/2011 - 04/2024
Designer Series® 5/2013 - 03/2019
Pella® 450 Series 5/2015 - 12/2018

Tools Required:

- Stiff blade putty knife or flat-blade screwdriver

1 Transition Seal Replacement:

Transition seals are a two-piece weatherstrip seal located on top of the sill at each jamb and on the bottom of the astragal on double doors.



Transition Seal Frame



Transition Seal Astragal

A. **Grasp and remove the bulb weatherstrip piece** from the kerf.



B. **Remove the flat weatherstrip piece** by grasping and removing from the kerf and from behind the frame/ astragal weatherstrip.



1 Transition Seal Replacement (continued):

C. **Pry out the frame/astragal weatherstrip** slightly to allow for clearance when replacing the flat weatherstrip piece.



D. **Install the flat weatherstrip piece** by inserting the barb on the back side into the kerf and the place edge behind the frame/astragal weatherstrip.





E. **If needed, use a straight blade screwdriver or stiff putty knife** to insert the bottom edge behind the threshold edge.



F. **Insert the bulb weatherstrip into the kerf.**



G. **Make sure the frame/astragal weatherstrip is fully seated in the kerf.**

