SERVICE INSTRUCTION

Balance Pocket Cover Replacement For Single-Hung and Double-Hung

These instructions apply to:

Pella® 250 Series 2014 - Current

Pella® 150 Series 2020 - Current

Tools Required:

- None

Supplies Needed:

- Balance Pocket Service Package

1 Balance Pocket Cover Replacement:

A. Unlock and Tilt out lower sash.

B. Hook lower portion of balance pocket cover with finger.

C. Pull balance pocket cover out.





D. Insert balance pocket cover into balance pocket and press cover until it **"snaps"** into place.









©2019 Pella Corporation