Sliding Patio Door Glazing Bead Replacement

SERVICE INSTRUCTION

03/2026-Current

Tools Required:
- Hook tool
- Putty knife

1 Glazing Bead Replacement:

A. **Stile glazing beads must be removed first.** Starting at one of the ends, use a putty knife perpendicular to the inside edge of the glazing bead to get a slight amount of separation of the bead from the groove. Once slightly separated use a hook tool to pull the glazing bead off.







B. **On the bottom rail,** similar to step A, use a putty knife to get a small amount of separation of the glazing bead from the groove. Once slightly separated, use a hook tool to remove the glazing bead.







C. **Top rail glazing beads are removed** using the same process.

© 2026

GIF-000003116- Part Number: V990524

1 Glazing Bead Replacement (continued):

D. **Insert one end of the top rail glazing bead** and bow it in the center to insert the other end. Press bead into place along the length of the bead.
The top rail glazing bead installation process is like the bottom rail steps depicted in the photos in 1E.

E. **Insert one end of the bottom rail glazing bead** and bow it in the center to insert the other end. Press bead into place along the length of the bead.









F. **Install stile glazing bead** by placing one end against the top rail glazing bead. Press the bead into place along the length of the bead.









© 2026