VINYL WINDOWS AND DOORS

Manufactured by Pella Corporation **Questions? Call 1 (800) 374-4758**

SERVICE INSTRUCTION

Casement and Awning Snubber Replacement

These instructions apply to:

Pella® 250 Series Awning/Casement 4/2018 - Current

Tools Required:

- Phillips head screwdriver

Supplies Needed:

- Frame/Sash Snubber

Note: Remember to work safely while doing any maintenance or repair. This includes wearing safety glasses and using safe work practices. Make sure your work area is unobstructed and clear of window coverings, etc.

Casement process shown in the following steps, awning process is similar

1 Frame Snubber Replacement:

Casement Screen and Roto Cover Removal process shown in Step 1, awning process is similar.

A. Remove the screen, unlock sash and open to its fully open position.





B. Unlock window and crank open window sash to access the snubber. Note the alignment of the snubber and remove the snubber attachment screws.







© 2018 Pella Corporation

Part Number: V987374

1 Frame Snubber Replacement (continued):

C. Position snubber on frame in the same alignment as the one removed. Insert and tighten the attachment screws.









2 Sash Snubber Replacement:

A. Unlock window and crank open window sash to access the snubber. Note the alignment of the snubber and remove the snubber attachment screws.







B. Position snubber on sash in the same alignment as the one removed. Insert and tighten the attachment screws.







2 Sash Snubber Replacement (continued):

C. Crank window closed, fold down crank and engage lock.

Install the screen and engage the screen clips.



