VINYL WINDOWS AND DOORS

Manufactured by Pella Corporation

Questions? Call 1 (800) 374-4758

SERVICE INSTRUCTION

Casement Hinge Track Stop Replacement

These instructions apply to:

Pella® 250 Series Awning/Casement 4/2018 - Current

Tools Required:

- Phillips head screwdriver

Supplies Needed:

- Hinge Track Stop

Note: Remember to work safely while doing any maintenance or repair. This includes wearing safety glasses and using safe work practices. Make sure your work area is unobstructed and clear of window coverings, etc.

1 Hinge Track Stop Replacement:

A. Remove the screen by disengaging the screen clips and lifting out of the frame. Unlock sash and open to its fully open position.





B. Remove the stop attachment screw located in the head hinge slide and then remove the stop.







© 2018 Pella Corporation

Part Number: V987377

1 Hinge Track Stop Replacement (continued):

C. Insert the stop into the head hinge slide and insert and tighten the attachment screw.









D. Crank window closed, fold down crank and engage lock.

Install the screen and engage the screen clips.



