Pella® Impervia® Sliding Patio Door – Lock Strike

Installation Instruction

These instructions apply to:

Sliding Patio Door Model 2.0
06/2021 - Current

Tools Required:

- Phillips screwdriver

Parts Required:

- 2 Strikes,
  2 Covers,
  4 short screws,
  4 long screws



1 Lock Strike Installation:

A. **For Grade 10 Forced Entry performance;** Install 1 strike using 2 short screws and 2 long screws in a diagonal pattern.

For Grade 40 Forced Entry performance install 4 long screws in each strike.

All long screws should contact solid lumber framing. Shim behind strikes when installing long screws to ensure jambs stay straight and plumb.









B. Install cover over the strike.





C. Repeat A & B on the other strike.



© 2021 Pella Corporation

GIF-000002719- Part Number:82LE0000

1 Lock Strike Installation (continued):

D. Type 3 OXO units are supplied with pre-installed torx head screws supported by a backer plate.

   In this configuration strike anchor screws cannot be installed into framing.

   Do not replace these screws.

   If strike adjustment or replacement is needed adjust one strike at a time to ensure backer plate does not move during adjustment process.



© 2021 Pella Corporation