# Sill Nose Cover Installation Instructions

1. Cut sill nose cover to length (approximately 2" longer then existing sill).

2. Notch sill nose cover to fit existing exterior jamb trim. (Figure 1) **Note:** If existing wood sill is over 1-3/4" thick it must be reworked by removing wood on the bottom edge to 1-3/4" thickness.



Figure 1

3. Notch ends of sill nose cover and fold aluminum across each end of existing wood sill. Nail sill nose cover near the top edge to the existing wood sill using 7d galvanized box nails. (Figure 2)

4. Nail bottom edge to existing wood sill using 4d galvanized box nails.



Figure 2

5. Apply sealant along exterior trim and on ends of sill nose cover. (Figure 3)

   Sealants are listed in recommended order:
   Two-part polysulfide, Acrylic solvent base, Silicone, One-part polysulfide or Butyl. Follow sealant manufacturer's recommendation for specific applications.



Figure 3

© Pella Corporation