Monumental Double-Hung Limited Opening Hardware Kit

Installation Instruction

These instructions apply to:

Architect Series® 2005 - 2015

Tools Required:

- Drill with 1/8" bit
- Phillips head screwdriver
- Pencil

1 Installing the Limited Opening Bumper:

A. Open the sash so there is a 3-3/4" clear opening between the lower sash and the frame sill.

Tip: Place a 3-3/4" wood block between the sash and sill with the sash closed against the block.



B. Place a pencil mark 1/2" from the outer edge of the sash approximately 1/4" above the checkrail.



C. Place the bumper on the face of the upper sash with the bumper hole aligned with the pencil mark. Use the bumper as a drill template, drill a 1/8" diameter pilot hole approximately 1/2" deep.

Tip: A drill stop or masking tape may be used to insure proper pilot hole depth.



D. Attach the bumper to the upper sash using a #8 x 1 pan head screw.

E. Repeat B-D on the other side of the unit.

F. Remove the wood block. Raise and lower the sash to check the operation of the sash and for proper limited opening. The clear opening between the sash and sill should be 3-3/4".

G. Remove the release paper from the back of the limited opening warning label. Apply the label to the lower corner of the window glass opposite the unit identification label.



© 2007 Pella Corporation