INSTALLATION INSTRUCTION

Sliding Window Limited Opening Hardware

Tools Required:

- Saw
- Tape Measure
- Drill
- 1/4" Bit
- Phillips Driver

Supplies Needed:

- Limited Opening Kit

Note: Remember to work safely while doing any maintenance or repair. This includes wearing safety glasses and using safe work practices. Make sure your work area is unobstructed and clear of window coverings, etc.

1 Install Limited Opening Hardware:

A. Open the sash so there is a 3" clear opening between the sash and the window frame.

Tip: Place a 3" wood block between the sash and frame with the sash closed against the block.



B. Measure the distance between the vent sash stile (the side with the lock) and jamb of the window frame. This will be the length to cut the limited opening stop.



C. Cut limited opening stop to length determined.

D. Drill a 1/4” pilot hole on each end of the limited opening stop 1” from each end and 1/2” from one side.



© 2025 Pella Corporation

GIF-000003084- Part Number: V985118

1 Install Limited Opening Hardware (continued):

E. Remove the vent stop from the head of the window.





F. Insert limited opening stop by pushing it into the head pocket until it snaps into place.







G. Install the two provided screws.







© 2025 Pella Corporation