Reinforcing Strike Kits for Trilennium® Multi-Point Locks



Installation Instructions

Tools Required:



Phillips Screwdriver

The jambs should already be routed for these strike plates.

1. Attach the dust box to the reinforcing plate.
   a. The dust box feet should align with the slots in the reinforcing plate.
   b. The reinforcing plate arms should sit inside the dust box.
2. Align the three holes on the strike plate with the reinforcing plate.
3. Use 3/4" screws in the top and bottom holes of each strike.
4. Use long #10 x 2-1/2" screw in center hole (The purpose is to anchor each strike plate to the structural framing for added security)
5. Repeat for the remaining strike locations.



