SERVICE INSTRUCTION

Casement & Awning Crank Handle and Roto Cover Replacement

Tools Required:

- Small flat-head screwdriver

Supplies Needed:

- Roto operator cover
- Crank handle

Note: Remember to work safely while doing any maintenance or repair. This includes wearing safety glasses and using safe work practices. Make sure your work area is unobstructed and clear of window coverings, etc.

Casement process shown in the following steps, awning process is similar.

1 Crank Handle and Roto Cover Replacement:

A. Remove the crank handle, by loosening the set screw with a small flat-head screwdriver, and set aside. To install, place handle on operator stud and tighten set screw.





B. Remove the roto crank cover by pulling the cover from the frame. To install, position cover over roto operator and snaps cover in place.





© 2025 Pella Corporation

GIF-000003090- Part Number: V987373