Sliding Door Extended Bumpers for Premium Handle Kit

Installation Instruction

These instructions apply to:

Architect Series® 01/2006 - 03/2019
Designer Series® 01/2006 - 03/2019
Pella® Lifestyle Series Triple-Pane 04/2019 - Current

Tools Required:

- Phillips screwdriver
- Sealant gun with sealant


1 Head Bumper Replacement:

A. Loosen the bumper attachment screws at the frame head; remove bumper.





B. Place provided screws in holes of the extended head bumper until they protrude slightly out of the flat side.



C. Align the bumper screws with the holes at the head of the frame.





D. Tighten the screws. **DO NOT** overtighten.

© 2019 Pella Corporation

2 Sill Bumper Replacement:

A. Loosen the bumper attachment screws at the frame sill, if present; remove bumper. If bumper is on the sill track, pull up to lift bumper off track.







B. Press extended sill bumper onto the sill track. Push the bumper to position against the frame.





C. If present, insert sealant into the screw holes and insert previous bumper screws. Sealant only may be used if the holes are completely filled.







© 2019 Pella Corporation