SLIDING PATIO DOOR SILL RISER

INSTALLATION INSTRUCTIONS

Parts List:


- Sill riser


Tool List:


- Sealant gun with sealant

1 Install Sill Riser:

A. **Apply two continuous 1/4" to 3/8" diameter beads of sealant 1/2" apart across the entire length of the sill riser.** Attach the sill riser as shown. DO NOT smear sealant lines, as this will damage the lines and may allow water to penetrate the building.







© 2026

GIF-000003109- Part Number: V990517