Casement Removable Full Screen

Installation Instruction

These instructions apply to:

Pella® 450 Series 1991-03/2019
Pella® Lifestyle Series Dual-Pane 04/2019-Current


IMPORTANT:
Read carefully before beginning.




1 Installing The Removable Full Screen:

A. Make sure the screen clips are fully retracted and do not protrude beyond the edge of the frame.

B. Grasp the screen by the edges and place it into the window from the room side.





C. Push the screen frame tightly against the window at the clip locations.

D. Use your thumb to press the clip into the plastic strike. Repeat until all clips are secure. If the clips do not fully engage, adjust the screen slightly.





© 2019 Pella Corporation

Estas instrucciones se aplican para:

Serie 450 de Pella®: de 1991 al presente


IMPORTANTE:
Lea cuidadosamente antes de comenzar.




1 Instalación de la malla corrida desmontable:

A. Compruebe que los sujetadores de la malla estén totalmente retraídos y que no sobresalen del borde del marco.

B. Agarre la malla por los bordes y colóquela dentro de la ventana de adentro hacia afuera.





C. Presione el marco de la malla firmemente contra la ventana en los puntos de los sujetadores.

D. Con el dedo pulgar presione el sujetador dentro del conector. Repita hasta que todos los sujetadores estén asegurados. Si los sujetadores no calzan completamente, ajuste levemente la malla.





© 2019 Pella Corporation