INSTALLATION INSTRUCTION

Double-Hung Sash Lift

Tools Required:


- Drill
- 3/32" (2.4mm) dia. drill bit
- Pencil
- #2 Phillips screwdriver

Tools Required:

- Double-Hung Sash Lift Package



1 Preparing and Installing the Sash Lift:



A. Align the dashed line (B) with the top of the lower wood section of the window (B) centering it below the window lock(s). (See diagram.)


B. Drill two 3/32" (2.4mm) diameter pilot holes to a maximum depth of 3/8" (10mm) through the two holes marked (B) on the template.

C. Attach the sash lift with the screws provided. **DO NOT OVERTIGHTEN** the screws.

CAUTION!

Drilling deeper than 3/8" (10 mm), may cause glass breakage.

Note: When printing the template; make sure the printer page scaling is set to "None" or page sizing is set to "Actual".



INSTALLATION INSTRUCTION

Double-Hung Sash Lift

Tools Required:


- Drill
- 3/32" (2.4mm) dia. drill bit
- Pencil
- #2 Phillips screwdriver

Tools Required:

- Double-Hung Sash Lift Package



1 Preparing and Installing the Sash Lift:



A. Align the dashed line (B) with the top of the lower wood section of the window (B) centering it below the window lock(s). (See diagram.)

B. Drill two 3/32" (2.4mm) diameter pilot holes to a maximum depth of 3/8" (10mm) through the two holes marked (B) on the template.

C. Attach the sash lift with the screws provided. **DO NOT OVERTIGHTEN** the screws.

CAUTION!

Drilling deeper than 3/8" (10 mm), may cause glass breakage.

Note: When printing the template; make sure the printer page scaling is set to "None" or page sizing is set to "Actual".

