SERVICE INSTRUCTION

Vent Stop Replacement–Sliding Window

These instructions apply to:

Centera by Pella™ 02/2007 - 2011
ThermaStar by Pella® 2003 - 01/2022
Encompass by Pella® 02/2008 - Current

Tools Required:

- Flat-head screwdriver

Supplies Needed:

- Vent stop



Two or more people will be required for the following instruction!

Note: Remember to work safely while doing any maintenance or repair. This includes wearing safety glasses and using safe work practices. Make sure your work area is unobstructed and clear of window coverings, etc..

1 Replacing The Vent Stop:

A. Pry up on the end of the vent stop with a flat-head screwdriver.



B. Grasp it with fingers and pull up and away from the window frame.



C. Position the new vent stop in the corner and press it down until it is flush with the window frame.

© 2007 Pella Corporation