SERVICE INSTRUCTION

Patio Door Heavy Duty Screen Handle Replacement

These instructions apply to:

Pella® 150 Series 02/2020 - Current
Centera by Pella™ 02/2007 - 02/2012
ThermaStar by Pella® 2003 - 03/2021
Encompass by Pella® 02/2008 - Current

Tools Required:

- Phillips-head screwdriver

Supplies Needed:

- Replacement screen handle

1 Removing the Screen Handle:

A. Unlatch and slide the screen open.

B. Remove the two attachment screws located on the interior handle. Note the orientation of the latch operator in the exterior handle. Remove the exterior handle.







C. Remove the interior handle with the attached latch from the screen frame. Note the orientation of the latch.

TIP: Pushing on the back side of the interior handle may help in removing the handle from the screen frame.





©2021 Pella Corporation