Sliding Patio Door Roller Adjustment

SERVICE INSTRUCTION

These instructions apply to:

Vinyl Sliding Patio Door 05/2024 - Current
Vinyl Multi-Slide Patio Door 05/2024 - Current

Tools Required:

- Putty knife
- Suction cup
- Phillips screwdriver
- Extra hole plugs

Note: It is recommended to have extra hole plugs on hand as the hole plugs can be damaged during removal.

1 Roller Adjustment:

A. Remove the hole plugs using a putty knife.





B. Insert a Phillips screwdriver and turn the screwdriver clockwise to raise that side of the panel or counterclockwise to lower the side of the panel.

TIP: Use a suction cup to lift the panel to take the weight off the roller while adjusting.





© 2026

GIF-000003008-1 Part Number: V989710

1 Roller Adjustment (continued):

Before roller adjustment
(Larger gap between panel and frame at bottom)



After roller adjustment
(Even gap between panel and frame from top to bottom)



TIP: Panel should slide smoothly, but still engage with the weatherstripping.

C. Install the hole plugs.



