Hinged Door Height Adjustment

SERVICE INSTRUCTION

These instructions apply to:

Vinyl Hinged Door 05/2024 - Current

Tools Required:

• Allen wrench

1 Height Adjustment:

A. Insert #6 Allen wrench into the bottom of the hinge. Turn clockwise to lift panel; counterclockwise to lower.







Up and down adjustments: adjust ALL hinges evenly to distribute the weight evenly.

B. Adjust each panel the same amount of turns to ensure all panels are adjusted the same.

© 2026

GIF-000003011-1 Part Number: V989713