Hinged Door Side-to-Side Adjustment

SERVICE INSTRUCTION

These instructions apply to:

Vinyl Hinged Door 05/2024 - Current

Tools Required:

- Allen wrenches (#3 & #5)
- Phillips screwdrivers (#2 & #3)

1 Side-to-Side Adjustment:

A. Use a #3 Allen wrench and loosen the hinge set screw on the back of the hinge.





B. Remove the hinge cover.





C. Loosen (do NOT remove) the hinge attachment screws.











© 2026

GIF-000003012-1 Part Number: V989714

1 Side-to-Side Adjustment (continued):

D. Use a #5 Allen wrench to move (adjust) the hinge side-to-side; clockwise will open gap and counterclockwise will close gap.





E. Re-tighten the hinge attachment screws. Do not overtighten!









F. Reinstall the hinge cover.



G. Re-tighten the hinge set screw.



