Sliding Patio Door Handle / Lock Replacement and Lock Throw Adjustment

SERVICE INSTRUCTION

03/2026-Current

Tools Required:

- Flat blade screwdriver
- Phillips screwdriver

NOTE: Standard / Standard Pull handle style lock throw adjustment shown.

1 Handle Removal:

A. **Remove the handle attachment screws.**







B. **Remove the handles from the door panel.**





2 Lock Replacement:

A. **Remove the lock attachment screws.** These two screws are located at the top and bottom of the lock.







© 2026

2 Lock Replacement (continued):

B. **Remove the lock from the door panel edge**.





C. **Insert replacement lock into the door panel edge**.





D. **Insert and tighten the lock attachment screws**.





3 Handle Installation:

A. **Insert the thumbturn tail into the lock slot**.





NOTE: Handles are provided configured for a XO door. If an OX door handle was ordered the following steps must be performed on the handle before installing the handle:

1) Remove the two screws on the back of the exterior handle leaving the existing washers in place.
2) Flip the handle 180 degrees for the proper orientation of the key cylinder.
3) Reinstall the handle attachment screws.





NOTE: Be sure to reuse the washers under each attachment screw head.

Pinch the medallion clip from the interior side of the handle escutcheon plate and rotate 180 degrees, insert the medallion into the interior handle escutcheon plate ensuring any logo script is upright if applicable when the handle is installed.

3 Handle Installation (continued):

B. **Position the Interior handle on the door panel** with the escutcheon plate cut-out over the thumbturn.






C. **Position the Exterior handle on the door panel,** be sure the exterior handle is facing the correct way.




D. **Insert and tighten the handle attachment screws.**




E. **Test the handle and lock lever.**

4 Lock Throw Adjustment:



Double screw adjustment: Each adjustment works independently for each hook. Clockwise will move the one hook further from the panel and counterclockwise will move it closer to the panel.

A. **With the door unlocked and open,** depress the anti-slam button and turn the thumbturn to extend the lock hooks.

B. **Starting on the adjustment screw by the top hook,** turning the screw counterclockwise will move the one hook closer to the panel; turning the screw clockwise will move it further from the panel.





C. **The lower hook is adjusted in the same manner**.





D. **Close and lock the door to test the lock works properly;** adjust as needed.